

# STRUCTURAL POCKET GUIDE



This document is intended as a concise tool for students to assess the impact of choices on the structure in their design.

Various basic cases are mentioned; for other cases, reference is made to literature.

The document is written in the context of Belgian construction: in particular the chapters with a red background are dependent on the national context, but it also explains why seismic loads are not addressed here.

Additional references and explanations - see Devriese T. 2025 "Structural pocket guide for architecture students."

Knowledge databases such as Buildwise and standards - on mynbn.be - are accessible via the Ghent University library.



Print recto-verso on A3 settings: no scaling, flip over short edge

## Approach to structural design

1. Conceptualize the structure and load transfers in the design. The structure ensures that all loads - both vertical (due to e.g. gravity) and horizontal (due to e.g. wind) - are transferred to the foundation. The structure is divided into elements, causing the loads to 'descend' according to the principles:
  - action = reaction
  - the whole, and each element is in equilibrium.
2. Estimate the loads. (see 3)
3. Quantify the load transfers. (see 4)
4. Determine the occurring normal forces/shear forces/moments/reactions due to the heaviest combination (see 6), making use of load combinations (see 5)
  - Grosso modo:
  - strength (stress): ULS
  - deflection: SLS
5. Determine the stress/deflection occurring in the element you want to design/verify. (see 7/8)
6. Determine whether these are smaller than the allowable stress (see 11) / maximum deflection (see 9) of the structural element chosen. - see 12 for columns.


## Further reading

### > Basic tables

- Elaborate sets of rules of thumb:
  - > Table 14.1-18 pD2/281, ff. in Van Herwijnen. 2010. *Polytechnisch zakboek*. 52th ed.
  - > 2.2.3 p77, ff. in Evans. 2014. *Structural Engineering for Architects*.
- Standard sizes wood products
  - houtinfo.be
- List of standard steel profiles
  - > pC2/1, ff. Van Herwijnen. 2010. *Polytechnisch zakboek*. 52th ed.
- Buckling tables : see section 'columns'

### > Pocket guides

- van Herwijnen, e.a. 2010. *Polytechnisch zakboek*. 52th ed.
- Cobb, Fiona. 2004/2015. *Structural engineer's pocket book* (: Eurocodes). context of United Kingdom.
- Iano, Joseph, and Edward Allen. 2022. *The architect's studio companion : rules of thumb for preliminary design*. Elaborate set of rules of thumb, including a chapter on structural elements.
- McMullin, Paul, and Jonathan Price. 2016-2019. *Architect's Guidebooks to structures*.



1 kN = ~100kg  
 1 N/mm = 1 kN/m  
 1 N/mm² = 10³ kN/m² = 1 MPa  
 1 Nmm = 10⁻⁶ kNm


## 1 RULES OF THUMB

| Type of member   | Approximate ratio l/d                          |
|------------------|--|
| beam<br>         | Lightly loaded l/d=20<br>Heavily loaded l/d=18 |
| slab<br>         | Simply supported l/d=30                        |
| cantilever<br>   | Fixed at one end l/d=7                         |
| truss<br>        | Simply supported l/d=14                        |
| portal frame<br> | l/d=40   |


Table based on Gauld, B. 1995. Structures for architects. p.10 - see introduction — for a list of sources with more elaborate tables.

## 2 GLOBAL STABILITY


Horizontal stability is secured by bracing it, with the help of walls / vertical elements.



Minimal three, axes do not go through one point.



By preference, the elements are positioned symmetrically, with the largest possible distance.



## 3 LOADS

These values are 'characteristic' values

### Permanent loads P

| Surface loads  | [kN/m²]                        | density (volumetric weight) (density.thickness = surface load) [kN/m³] |
|--|--------------------------------|--|
| total weight of building per floor incl. mobile loads, façades,... (estimations for columns/foundations) | heavy 12<br>light 10           | steel 78,5<br>concrete reinforced 25<br>tiles ceramic 25<br>glass 25   |
| green roof   | extensive 2,0<br>intensive 5,5 | sand dry / wet 16 / 20<br>masonry brick 18<br>chape 19<br>water 10     |
| solar panels incl. ballast   | 0,3                            | wood softwood (pine) 5,5<br>OSB, multiplex 7<br>CLT 4,4                |
| tiled roof (beams 8x23 cm, c.t.c. 1,4 m, insulation 300 mm, roof boarding 18 mm & ceramic roof tiles)    | 0,8                            |  |
| light walls < 2kN/m per length of wall   | 0,8                            |  |
| < 3kN/m per length of wall   | 1,2                            |  |

### Mobile loads Q

| Areas for domestic and residential activities :  | floors | stairs | [kN/m²]  |
|--|--------|--------|----------|
| Balconies  |        |        | 4 (min.) |
| Offices areas (public areas not susceptible to crowding)   |        |        | 3        |
| Public areas where people can congregate   |        |        |          |
| • Areas with tables (eetzalen, cafés, leeszalen,...)   |        |        | 3        |
| • Areas with fixed seats (theaters, lecture halls, waiting rooms,...)  |        |        | 4        |
| • Areas without obstacles for moving people (areas in museums, corridors in public buildings sports halls, concert halls, ...)           |        |        | 5        |
| Areas for archive, storage and industrial usage  |        |        |          |
| • Areas susceptible to accumulation of goods , including access areas (such as archives)   |        |        | 7,5      |
| • Industrial usage   |        |        | 5        |
| Garages and vehicle traffic areas  |        |        |          |
| • Traffic and parking areas for light vehicles (≤ 30kN ) such as garages, parking halls  |        |        | 2,5      |
| • Traffic and parking areas for medium vehicles (30kN ≤ 160kN ) such as access routes, delivery zones, zones accessible to fire engines. |        |        | 5        |
| Roofs: not accessible except for normal maintenance and repair. This value is a rule of thumb and includes snow and wind pressures       |        |        | 1        |
| Wind (Rule of thumb!)  |        |        | 1        |

Online tool for precise wind loads: eurocodeapplied.com or 'WInt' via Buildwise

Based on Eurocode NBN EN 1991-1-1 & ANB - chapter 6.3

## > reference works

- Sandaker, Bjørn Normann, e.a. 2019. *The structural basis of architecture*. Third edition.
- Muttoni, Aurelio. 2011. *The art of structures*.
- Arends, Jan, e.a. 2022. *Vademecum voor draagconstructies van gebouwen*. Chair of Structural Design and Mechanics, TUDelft
- Kdodadadi, Anahita. 2022. *Basic Concepts of Structural Design for Architecture Students*. Portland State University.
- Evans, Peter, et.al. 2014. *Structural Engineering for Architects*.
- Möller, Eberhard, e.a. 2022. *Manual of structural design*.
- Hunt, Tony. 2003. *Tony Hunt's Structures Notebook*.
- Lin, T. Y., and Sidney D. Stotesbury. 1981. *Structural concepts and systems for architects and engineers*.


## > basic principles

- Hunt, Tony. 2003. *Tony Hunt's Structures Notebook*.
- Lin, T. Y., en Sidney D. Stotesbury. 1981. *Structural concepts and systems for architects and engineers*.
- Provost, Michel, Philippe De Kemmeter, en David Attas. 2011. *Comment tout ça tient? Voyage au pays des structures*.
- Salvadori, Mario, Robert Heller, en Deborah Oakley. 2016. *Salvadori's Structure in Architecture*.


## 4 LOAD PATHS

- All loads (vertical & horizontal) are deviated to the foundations.
- Through load paths, you determine the loads on each element.

### Example: Vertical load path




### Loads and scheme of beam in roof




(total load) is the design value of the sum of the self weight, the permanent loading and the variable loading.

### Loads and scheme of intermediate wall



### Loads and scheme of portico



## 5 COMBINATIONS

Design values loading (general, unfavourable effect)

|      | G       | Q       |
|------|---------|---------|
| ULS* | γG=1,35 | γQ=1,50 |
| SLS  | γG=1    | γQ=1    |


\*rule of thumb:  
 ULS = characteristic load \* 1,4

ULS Ultimate Limit State (for stress,...)  
 SLS Serviceability Limit State (for deformations,...)

- γ safety factor
- d design value
- k characteristic value
- G permanent loading
- Q mobile loading

# 6 INFLUENCE GEOMETRY


(section) influences material tensions and deflections through the moment of Inertia I



An element with a higher I is more stiff, - the tension will be lower - the deformation will be lower than for an element with a lower I.

# MATERIAL

influences the deflection through modulus of elasticity E



A material with a higher E is more stiff, and thus deflects less under the same loading than a material with a lower E.

# LOADING & BOUNDARY CONDITIONS > BASIC CASES OF BEAM FORMULAS

|                              | Point load Q [kN]  | Distributed load q [kN/m]  |
|------------------------------|--|--|
| <b>Simply supported beam</b> | <p><math>M_{max} = \frac{1}{4} Ql</math></p> <p>Deflection <math>\Delta_{max} = \frac{1}{48} \frac{Ql^3}{EI}</math></p>  | <p><math>M_{max} = \frac{1}{8} ql^2</math></p> <p>Deflection <math>\Delta_{max} = \frac{5}{384} \frac{ql^4}{EI}</math></p>   |
| <b>2 fixed end</b>           | <p><math>M_{max} = -\frac{1}{8} Ql</math></p> <p><math>M_{max} = \frac{1}{8} Ql</math></p> <p>Deflection <math>\Delta_{max} = \frac{1}{192} \frac{Ql^3}{EI}</math></p> | <p><math>M_{max} = -\frac{1}{12} ql^2</math></p> <p><math>M_{max} = \frac{1}{24} ql^2</math></p> <p>Deflection <math>\Delta_{max} = \frac{1}{384} \frac{ql^4}{EI}</math></p> |
| <b>Cantilevers</b>           | <p><math>M_{max} = Ql</math></p> <p>Deflection <math>\Delta_{max} = \frac{1}{3} \frac{Ql^3}{EI}</math></p>   | <p><math>M_{max} = -\frac{1}{2} ql^2</math></p> <p>Deflection <math>\Delta_{max} = \frac{1}{8} \frac{ql^4}{EI}</math></p>  |

More cases: van Herwijnen, et al. 2010. Polytechnisch zakboek. 52e druk. p.B2/29 e.v., online by looking for 'Beam formulas'. Online tools (for more complex situations and/or more load cases): Skyciv.com and Clearcalcs.com

# 7 BASIC FORMULAS

$M = F e$   
 $\sigma = \frac{F}{A} = \frac{M}{W} = \frac{Mz}{I}$   
 $\Delta l = \frac{Fl}{EA}$   
 $\sigma = E \epsilon$   
 $\epsilon = \frac{\Delta l}{l}$

M moment [Nm]  
 F force [N]  
 e eccentricity [mm]  
 z lever arm [mm]  
 $\sigma$  stress [N/mm<sup>2</sup>]  
 A surface [mm<sup>2</sup>]  
 E elasticity [N/mm<sup>2</sup>]  
 l length [mm]  
 $\Delta l$  elongation [mm]  
 $\epsilon$  strain [-]


# CROSS SECTION: RECTANGLE

cross section  $A = \int dA$   $A = bh$   
 moment of inertia  $I_y = \int z^2 dA$   $I_y = \frac{bh^3}{12}$   
 $I_z = \int y^2 dA$   $I_z = \frac{hb^3}{12}$   
 section modulus (bending)  $W_y = \frac{I_y}{z}$   $W_y = \frac{bh^2}{6}$   
 $W_z = \frac{I_z}{y}$   $W_z = \frac{hb^2}{6}$

# CONTINUOUS BEAMS

Cantilevers and/or continuous beams are beneficial for moment distribution and deflection.

See below how the zone between the supports behaves like a beam with two fixed ends, and how the outer zones behave like cantilevers over the support.



special case if  $a=0,353 \cdot b$  then  $M_1=M_2$  and  $M_1+M_2 = \frac{ql^2}{8}$  (= Mmax distributed load & 2 simple supports)

# 10 MATERIAL

| Material-properties (characteristic)            | Wood (C24) | Concrete (C30/37) | Steel (S235) | Masonry |
|---|------------|-------------------|--------------|---------|
| Elasticity E [N/mm <sup>2</sup> ]               | 11000      | 33000             | 210000       | 5000    |
| Mass density $\rho$ [kg/m <sup>3</sup> ]        | 350        | 2500              | 7850         | 1800    |
| tensile strength $f_t$ [N/mm <sup>2</sup> ]     | 14,5       | 2,9               | 235          | 0,05    |
| compression strength $f_c$ [N/mm <sup>2</sup> ] | 21         | 30                | 235          | 5-25    |
| bending strength $f_m$ [N/mm <sup>2</sup> ]     | 24         | 3                 | 235          | 0,05    |

# 8 INTERNAL FORCES

**Tension**  $\sigma_t = \frac{N_{td}}{A} \leq f_{td}$   
**Compression**  $\sigma_c = \frac{N_{cd}}{A} \leq \omega_{buc} f_{cd}$   
**Bending**  $M = F \cdot e$   $\sigma_m = \frac{Mz}{I}$   
**Shear**  $\tau_{max} = \frac{3V}{2A}$   $\tau_{adm} = \frac{\sigma_{adm}}{\sqrt{3}}$  (Von Mises)  
**Torsion**  $M_{wr} = F \cdot e$

d 'design value' (incl. safety factors - see 11)  
 t tension  
 c compression  
 m moment  
 adm admissible  
 $\sigma$  stress (acting) [N/mm<sup>2</sup>]  
 $\tau$  optredende schuifspanning [N/mm<sup>2</sup>]  
 f admissible stress [N/mm<sup>2</sup>]  
 N normal force [N]  
 M moment [Nmm]  
 V shear [N]  
 T torsional moment [Nm]  
 z distance to neutral axis [mm]  
 I moment of inertia [mm<sup>2</sup>]  
 W section modulus [mm<sup>3</sup>]  
 $\omega_{buc}$  reduction factor for buckling (< 1)

# 11 VERIFICATION LOAD < RESISTANCE

Basic beam verification - manual:  
 • Stress check: OK if the occurring stress (based on 'beam formulas' and 'internal forces') < permissible material stress - loads in ULS  
 • Deformation check: OK if the occurring deflection (based on 'beam formulas') < maximum deflection - loads in SLS

Online calculation tools for 'manual' verification: eurocodeapplied.com  
 For complex calculations: FEM software, e.g. 'Diamonds' (Buildsoft), 'RFEM' (Dlubal), 'Scia Engineer'.

# STEEL

Steel can be easily verified following the steps described above.

# Design value admissible material stress

$f_d = \frac{f_k}{\gamma_m}$   $\gamma_m$  (partial safety factor for material rule of thumb:  $\gamma_m = 1$ )

# REINFORCED CONCRETE


# Design value admissible material stress

$f_{cd} = \alpha_{cc} \frac{f_{ck}}{\gamma_c}$   $\gamma_c = 1,5$   $\alpha_{cc} = 0,85$

Concrete cracks and creeps, therefore it cannot as simply be verified through material stress. Formula to estimate efficient beam height  $d_{ec}$  based on moment (ULS)

$d_{ec} = 2,507 \sqrt{\frac{M_d}{b \cdot f_{cd}}}$   $d = 0,9h$

# 9 DEFORMATION



|  | 2 simple supports | cantilever |
|--|-------------------|------------|
| <b>Maximal vertical deformation</b>  |                   |            |
| Appearance: Total deflection due to all loads and time-dependent effects (creep, etc.) | $w_{abc}$ $l/300$ | $l/150$    |
| Finishing of floors  |                   |            |
| Larges sizes or firmly attached  | $w_{bc}$ $l/500$  | $l/500$    |
| Small sizes or attached with tolerance   | $l/350$           | $l/350$    |
| Flexible covering  | $l/250$           | $l/250$    |
| Finishing of ceilings  |                   |            |
| Plastered  | $w_{bc}$ $l/350$  | $l/175$    |
| Not plastered, suspended   | $l/250$           | $l/125$    |
| Roofing  |                   |            |
| stiff  | $l/250$           | $l/125$    |
| flexible   | $l/125$           | $l/125$    |
| Vertical walls (Cracking in partition walls and facades)                               |                   |            |
| Reinforced walls   | $w_{bc}$ $l/350$  | $l/175$    |
| Not reinforced, with large openings  | $l/1000$          | $l/500$    |
| Moveable walls   | $l/250$           | $l/125$    |
| Windows with glazing   |                   |            |
| No tolerance in relation to structure (e.g. sliding doors)                             | $w_{bc}$ $l/1000$ | $l/500$    |
| Tolerance in relation to structure   | $l/350$           | $l/175$    |
| Slope and drainage (towards the drain)   |                   | > 2%       |
| Vibration  |                   |            |
| General (if natural frequency < 3,5Hz)   | $w_a$ 20 mm       |            |
| Sports-, dance-, and concert halls (if natural frequency < 7Hz)                        | 5 mm              |            |

# Maximal horizontal deformation

Balustrade: horizontal displacement of handrail  $h/100$   
 Facade glazing: horizontal displacement due to wind  $y/225$  (max 13mm)

Based on NBN B03-003 (based on reference in NBN EN 1990 ANB. The eurocode does not give limitations for deformations.) Horizontal displacement balustrades: NBN B03-004, on facade due to wind: Buildwise 'Dimensioneringsmethode rapport 11'

# MASONRY

Design value admissible material stress

$\sigma_{max,d} = 1 \text{ N/mm}^2$

# WOOD

Wood is an anisotropic material; the grain direction is very important for the material properties. Product type, load duration and humidity have a significant influence. online tool for verifications: calculatis.storaenso.com

# Design value admissible material stress

$f_d = k_{mod} \frac{f_k}{\gamma_m}$

**kmod** (effect load duration and humidity) rules of thumb for normal humidity, floor in house:

- timber, GL, LVL, multiplex: 0,5
- CLT 0,8
- other 0,2

elaborate table: NBN EN 1995-1-1 table 3.1

$\gamma_m$  (partial safety factor for material)

- LVL, multiplex, OSB 1,2
- other 1,3

elaborate tabel: NBN EN 1995-1-1 table 2.3

# Final deformation $E_{fin}$

In the case of wood, the final deformation depends on the humidity

$E_{fin} = \frac{E}{1 + k_{def}}$

# kdef


rule of thumb for inner spaces ('normal humidity'):

- timber, GL, LVL 0,6
- multiplex, CLT 0,8
- other 2,25

elaborate table: NBN EN 1995-1-1 table 3.2

# 12 COLUMNS

In an imperfect world, elements in compression can buckle and zones in compression in beams are prone to 'lateral torsional buckling'.



'braced' means that other elements secure global stability, which makes sure that ends cannot displace horizontally (see 2.)

$F_{buc} = \frac{\pi^2 EI}{l_k^2}$

Carefull! The elastic buckling load  $F_{buc}$  does not consider relative slenderness. Verification happens through tools.

**Buckling tables** give maximal loading for standard steel profiles as a function of the buckling length  $l_k$ , they thus allow to select a fit tubular profile from the tables when the load is known. See Herwijnen, et al. 2010. Polytechnisch zakboek. 52e druk. p.D2/177 ff.

# PROFILE SELECTION

- least structurally efficient
- suitable for columns that are not slender and only lightly loaded
- suitable for lightly loaded columns
- efficient choice, easy connections
- structurally the most efficient choice, complex connexions